

[Sommaire](#)[Contact](#)

Kodak TMAX 100

Traitement à 20°C (68°F)

Stock = Pure

Révélateur	Dilution	Exposition (en ASA)	Temps (en minutes)
Ilford ID 11	Stock	100	9
Ilford ID 11	Stock	400	11
Ilford ID 11	1 + 1	100	12
Ilford Microphen	Stock	100	11
Agfa Rodinal	1 + 25	100	6
Agfa Rodinal	1 + 50	100	12
Kodak D 76	Stock	100	9
Kodak D 76	1 + 1	100	12
Kodak HC 110	1 + 31	100 / 200	7
Kodak HC 110	1 + 31	400	9 1/2
Kodak T-Max	1 + 4	100 / 200	8
Kodak T-Max	1 + 4	400	12
Kodak T-Max	1 + 4	800	10 1/2 (à 24°C)
Kodak Xtol	1 + 1	25 / 50	8
Kodak Xtol	1 + 1	100	9
Kodak Xtol	1 + 1	200	10
Kodak Xtol	1 + 1	400	12 1/2
Kodak Xtol	1 + 1	800	14 1/2
Kodak Xtol	1 + 2	25 / 50	11 1/2
Kodak Xtol	1 + 2	100	12 1/2
Kodak Xtol	1 + 2	200	14
Kodak Xtol	1 + 2	400	16
Kodak Xtol	1 + 2	800	18
Kodak Xtol	1 + 3	25 / 50	14 1/2
Kodak Xtol	1 + 3	100	16
Kodak Xtol	1 + 3	200	18
Kodak Xtol	1 + 3	400	20 1/2
Kodak Xtol	1 + 3	800	23

[Retour](#)