

[Sommaire](#)
[Contact](#)

Kodak TMAX 400

Traitement à 20°C (68°F)

Stock = Pure

Révélateur	Dilution	Exposition (en ASA)	Temps (en minutes)
Ilford ID 11	Stock	200	5 1/2
Ilford ID 11	Stock	400	7
Ilford ID 11	Stock	800	9 1/2
Ilford ID 11	1 + 1	200	9
Ilford ID 11	1 + 1	400	10 1/2
Ilford ID 11	1 + 1	800	16
Ilford ID 11	1 + 3	200	14 1/2
Ilford ID 11	1 + 3	400	16 1/2
Ilford Microphen	Stock	400	5 1/2
Ilford Microphen	Stock	800	8
Ilford Microphen	1 + 1	400	11
Ilford Microphen	1 + 1	800	16
Ilford Microphen	1 + 3	400	20
Ilford Perceptol	Stock	200	10 1/2
Ilford Perceptol	Stock	400	13
Ilford Perceptol	1 + 1	200	12 1/2
Ilford Perceptol	1 + 1	400	15
Ilford Perceptol	1 + 3	200	17
Ilford Perceptol	1 + 3	400	22
Agfa Rodinal	1 + 25	200	6
Agfa Rodinal	1 + 25	400	7
Agfa Rodinal	1 + 25	800	10 1/2
Kodak D 76	Stock	400	7
Kodak D 76	1 + 1	400	12 1/2
Kodak HC 110	1 + 31	400 / 800	6
Kodak HC 110	1 + 31	1600	8 1/2
Kodak T-Max	1 + 4	400 / 800	7
Kodak T-Max	1 + 4	1600	10
Kodak T-Max	1 + 4	3200	9 1/2 (à 24°C)
Kodak Xtol	1 + 1	100 / 200	8
Kodak Xtol	1 + 1	400	9
Kodak Xtol	1 + 1	800	9 1/2

Kodak Xtol	1 + 1	1600	11
Kodak Xtol	1 + 1	3200	12 1/2
Kodak Xtol	1 + 2	100 / 200	9 1/2
Kodak Xtol	1 + 2	400	10 1/2
Kodak Xtol	1 + 2	800	12
Kodak Xtol	1 + 2	1600	14
Kodak Xtol	1 + 2	3200	16
Kodak Xtol	1 + 3	200	12
Kodak Xtol	1 + 3	400	13 1/2
Kodak Xtol	1 + 3	800	15
Kodak Xtol	1 + 3	1600	17
Kodak Xtol	1 + 3	3200	20

[Retour](#)